

PULLMAN-HOLT

Operation & Care Instructions

F600 Blower Fan

The F600 is designed to operate in three speeds and three directional positions to meet a wide range of drying and ventilation applications.



Fan Unpacking

Remove the F600 from its original carton. Visually inspect for any signs of damage during transit. If there are any signs of damage, do not operate the unit. Contact Pullman-Holt customer service and do not discard the original packing materials since they may be required to transport the unit back to the factory.

WARNING

READ AND UNDERSTAND ALL WARNINGS AND INSTRUCTIONS BEFORE USING THIS PRODUCT.

Instructions

1. Do not use this fan near flammable materials, or vapors.
2. Do not expose this fan to water or rain, store indoors.
3. Never immerse, or wash the fan with water.
4. To unplug the cord, grasp the plug and pull.
5. Do not block openings of fan, or allow dust to accumulate on them.

6. Do not drop the fan.
7. To reduce the risk of electric shock, connect only to an outlet provided with a ground fault-interrupting device.
8. To reduce the risk of electric shock, use only with an extension cord type S, SO, ST, STO, SJ, SJT, SJO, or SJTO.
9. Make sure your extension cord is in good condition and be sure to use one heavy enough to carry the current your product will draw. An undersized extension cord will cause a drop in line voltage resulting in loss of power and overheating. If in doubt, use the next heavier gauge. The smaller the gauge number, the heavier the cord. Use no smaller than a # 16 awg extension cord.

Replacement Parts

B260867	Cord Set
B260868	Switch
B260869	Motor
B260870	Fan Wheel
B260871	Rubber Feet (4 required)

Pullman-Holt Corporation

10702 N 46th Street • Tampa, FL 33617
(813)971-2223 • fax (813) 971-6090
www.Pullman-Holt.com